

KÄHR'S LUXURY TILES

ADHESIVE LIST - DRY BACK

These adhesives are approved for Kährs LT Dry back installation

ARDEX AF 145
ARDEX AF 180 MS
Ball Styccobond F44, F46, F48 PLUS, F49, F74, F81, F94
Bostik Laybond HT
Bostik Nibofloor S 800
Bostik Power Elastic
Bostik Startac Power
CascoProff
CascoProff DC
CascoProff Extra
CascoThan 2K
CEGE Durocoll
Mapei Adesilex G20
Mapei Ultrabond Eco V4SP
Mapei Ultrabond Eco V4SP Fiber
Mapei Ultrabond Eco 4LVT
Schönox Durocoll
Thomsit K 188 E
Thomsit K 190 F
Uzin KE 66
Uzin KE 2000 S
Uzin KE 2428

Installation instructions, see: www.kahrs.com