

Maintenance guide

KÄHR'S UPOFLOOR ESTRAD ULTIMATE SD

Date: 05-2021

This document is universal instruction which can be used to create the cleaning program for the installed floorings. Cleaning program should be created by co-operation with cleaning experts paying attention to use and conditions.

It is recommended to use polyester pads under furniture legs to get flooring lasting in longer.

INITIAL CLEANING

Remove loose dirt by mopping or vacuuming.

Machine wash the floor with a combination or floor care machine. Use a red pads or medium-hard brushes, a weakly alkaline detergent, or an alkaline detergent solution for a more soiled floor. Avoid excessive use of water and make sure that the floor surface remains dry.

It is recommended to treat a clean and dry floor with a cleaning and care solution for ESD floor care (eg TASKI Jontec Destat).

POLISHES

The Kährs Upofloor Estrad Ultimate SD floor should not be waxed in the health care area. In another area when waxing is allowed you can use the applicable ESD wax.

ROUTINE MAINTENANCE

Use the machine whenever possible. The floor then stays cleaner. Remove dust and loose debris from the floor. For cleaning with scrubber drier or manual methods, use an ESD floor cleaning and care solution (eg TASKI Jontec Destat). For basic treatment, wet wipe the floor and allow the cleaning and care solution to dry on the floor. Treat the floor regularly.

BASIC CLEANING

Wash heavily soiled floors with an alkaline, if necessary strongly alkaline cleaning solution. Use a floor care machine or scrubber drier with red pads. Rinse thoroughly. Treat the floor with an ESD floor care agent (Destat).

After basic cleaning of the waxed floor, you can polish floor once with ESD wax.